




Parts Manual

Mfg. No: 12V332-0012-F1



Model Components	Page
Air Cleaner Group.	4
Blower Housing Group.	6
Carburetor Group.	8
Controls Group.	10
Crankcase Cover/Sump and Lubrication Group.	12
Crankshaft Group.	14
Cylinder Group.	16
Cylinder Head Group.	18
Exhaust Group.	20
Flywheel, Ignition, and Starter Group.	22
Fuel Supply Group.	24


Not For
Reproduction



Air Cleaner Group

REF NO	PART NO	QTY	DESCRIPTION
11	597013	1	TUBE, Breather
163	596768	1	GASKET, Air Cleaner
185	590692	1	NUT -(Air Cleaner Base)
259	691189	1	Bracket-Casing Clamp
265	691024	1	CLAMP, Casing
267	597027	1	SCREW -(Casing Clamp)
445	596760	1	FILTER, A/C Cartridge
467	596758	1	KNOB, Air Cleaner Cover
467A	596759	1	KNOB, Air Cleaner Cover
536	597060	1	CLEANER, Air
875	597061	1	BASE, Air Cleaner
968	597062	1	COVER, Air Cleaner
1406	597065	1	VALVE, Debris
1453	596756	1	SEAL, Air Cleaner Cover


Not For
Reproduction



Blower Housing Group


REF NO	PART NO	QTY	DESCRIPTION
60	-----	2	GRIP, Starter Rope -(Part information located in Flywheel/Ignition/Starter Group.)
65	-----	3	SCREW -(Part information located in Flywheel/Ignition/Starter Group.)
281	-----	1	PANEL, Control -(Part information located in Controls Group.)
304	597073	1	HOUSING, Blower -(For use on engines without electric start & without regulator)
305	597078	4	SCREW -(Blower Housing)
608	-----	2	STARTER, Rewind -(Part information located in Flywheel/Ignition/Starter Group.)
1036	-----	1	LABEL, Emissions -(Available from a Briggs & Stratton Authorized Dealer)
1319	797669	1	LABEL, Warning -(REQUIRED When Replacing Parts With Warning Labels Affixed)
1515	-----	1	NUT, Hex Flange -(Part information located in Controls Group.)

Not For
Reproduction




Carburetor Group

REF NO	PART NO	QTY	DESCRIPTION
38	595328	2	Screw -(Fuel Shut Off Valve)
51	596769	1	GASKET, Intake
51A	596770	1	GASKET, Intake
53	597052	1	STUD -(Carburetor) (Short)
53A	597051	1	STUD -(Carburetor) (Long)
104	797622	1	Pin-Float Hinge
105	797139	1	Valve-Float Needle
117	597453	1	JET, Main -(Standard)
118	597454	1	JET, Main -(High Altitude)
121	597138	1	KIT, Carburetor Overhaul -(Service Kits may include extra parts not specific to this engine.)
122	597050	1	SPACER, Carburetor
125	596764	1	CARBURETOR
133	597473		FLOAT, Carburetor
137	798932	1	Gasket-Float Bowl
163	596768	1	GASKET, Air Cleaner
185	-----	1	NUT -(Part information located in Air Cleaner Group.)
202	597033	1	LINK, Mechanical Governor
209	597115	1	Spring, Governor
240	597039	1	FILTER, Fuel
245	597042	1	GASKET, Fuel Bowl -(Use Before Date Code 18051700)
245	597735		GASKET, Fuel Bowl -(Use After Date Code 18051600)
246	597043	1	BOWL, Fuel Filter
254	595322	1	Drain-Carburetor Bowl
276	797632	1	Washer-Sealing
315	595320	1	Seal-O Ring -(Fuel Filter Bowl)
472A	597602		KNOB, Choke Shaft -(Pewter)
692	797134	1	Spring-Detent
951	597044		LEVER, Choke
958	597040	1	VALVE, Fuel Shut Off
975	597049	1	BOWL, Float



Controls Group


REF NO	PART NO	QTY	DESCRIPTION
188	590850	2	SCREW -(Control Bracket)
202	597032	1	LINK, Mechanical Governor
202A	597033	1	LINK, Mechanical Governor
209	597115	1	Spring, Governor
211	691278	1	Spring-Governor
222	597657	1	BRACKET, Control
227	597028	1	LEVER, Governor Control
232	597034	1	SPRING, Governor Link
265	691024	2	CLAMP, Casing
267	597027	2	SCREW -(Casing Clamp)
278	690402	1	Washer -(Governor Control Lever)
281	597067	2	PANEL, Control
286	590702		MODULE, Oil Sensor
410	597024	1	LINK, Control
472	597025	1	KNOB, Choke Shaft -(Black)
505	590641	1	NUT -(Governor Control Lever)
562	597121	1	BOLT -(Governor Control Lever)
621	692310	1	Switch-Stop
629	597022	1	SPRING, Throttle Return
663	597460	2	SCREW -(Control Panel)
703	597021	2	CLIP
729	597019	2	CLIP, Wire
1054	845118	1	TIE, Cable
1136	597020	2	SCREW -(Control Bracket)
1305	590703		SCREW
1460	597035	1	BRACKET, Governor Control
1462	597036	1	SCREW -(Engine Control Unit) (ECU)
1515	590692	1	NUT -(Control Panel)



Crankcase Cover/Sump and Lubrication Group

REF NO	PART NO	QTY	DESCRIPTION
18	596896	1	COVER, Crankcase
20	596991	1	SEAL, Oil -(PTO Side)
22	590714	6	SCREW -(Crankcase Cover/Sump)
522	590716	2	PLUG, Dipstick/Fill
523	596992	1	DIPSTICK
847	596989	1	DIPSTICK/TUBE ASSEMBLY
850	100106	1	SEALANT, Liquid
1548	596990	1	BEARING, Ball -(Crankcase Cover/Sump)


Not For
Reproduction



Crankshaft Group






REF NO	PART NO	QTY	DESCRIPTION
16	596958	1	CRANKSHAFT
24	798869	6	Key-Drive Pulley
25	596978	1	PISTON ASSEMBLY - (.020 Oversize)
25	596977	1	PISTON ASSEMBLY
26	596980	1	SET, Ring - (.020 Oversize)
26	596979	1	SET, Ring
27	596982	1	LOCK, Piston Pin
28	596981	1	PIN, Piston
29	596983	1	ROD, Connecting
32	596984	2	SCREW - (Connecting Rod)
46	596993	1	CAMSHAFT
357	692191	1	Key-Drive Pulley

Not For
Reproduction




Cylinder Group

REF NO	PART NO	QTY	DESCRIPTION
1	596995	2	CYLINDER ASSEMBLY
3	596991	1	SEAL, Oil -(Magneto Side)
7	-----	1	GASKET, Cylinder Head -(Part information located in Cylinder Head Group.)
15	590678	2	PLUG, Oil Drain
17	596990	1	BEARING, Ball -(Cylinder)
20	-----	1	SEAL, Oil -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
51	-----	1	GASKET, Intake -(Part information located in Carburetor Group.)
51A	-----	1	GASKET, Intake -(Part information located in Carburetor Group.)
219	597038	1	GEAR, Governor
276	797632	1	Washer-Sealing
306	597076	1	SHIELD, Cylinder -(Bottom)
306A	597077	1	SHIELD, Cylinder -(Top)
307	590850	3	SCREW -(Cylinder Shield)
307A	590683	3	SCREW -(Cylinder Shield)
307B	590638	1	SCREW -(Cylinder Shield)
358	597139	1	GASKET SET, Engine -(Service Kits may include extra parts not specific to this engine.)
404	597030	1	WASHER -(Governor Crank)
585	-----	1	GASKET, Breather Passage -(Part information located in Cylinder Head Group.)
615	597031	1	RETAINER, Governor Shaft
616	597029	1	CRANK, Governor
718	590713	2	PIN, Locating
799	590703		SCREW
850	-----	1	SEALANT, Liquid -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
868	597001	1	SEAL, Valve
883	-----	1	GASKET, Exhaust -(Part information located in Exhaust Group.)
1022	-----	1	GASKET, Rocker Cover -(Part information located in Cylinder Head Group.)
1052	590671	1	SENSOR, Oil
1453	-----	1	SEAL, Air Cleaner Cover -(Part information located in Air Cleaner Group.)
1548	-----	1	BEARING, Ball -(Part information located in Crankcase Cover/Sump and Lubrication Group.)



Cylinder Head Group


REF NO	PART NO	QTY	DESCRIPTION
5	596998	1	HEAD, Cylinder
7	597007	1	GASKET, Cylinder Head
13	597008	4	SCREW -(Cylinder Head)
21	597014	1	CAP, Oil Fill
33	597005	1	VALVE, Exhaust
34	597004	1	VALVE, Intake
35	597002	1	SPRING, Valve -(Intake)
36	597002	1	SPRING, Valve
40	590654	2	RETAINER, Valve
45	591449	2	TAPPET, Valve
51A	596770	1	GASKET, Intake
155	592874	1	PLATE, Cylinder Head
192	597006	2	ADJUSTER, Rocker Arm
238	590649	2	CAP, Valve
296	590631	2	STUD -(Muffler)
337	597383	2	PLUG, Spark
383	19576S	1	WRENCH, Spark Plug
553	597003	1	RETAINER, Valve Spring
580	809894	1	SEAL, O-Ring -(Oil Fill Cap)
584	597011	1	COVER, Breather Passage
585	597010	1	GASKET, Breather Passage
684	597012	2	SCREW -(Breather Passage Cover)
718A	590637	2	PIN, Locating
798	597000	2	SCREW -(Rocker Arm)
850	-----	1	SEALANT, Liquid -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
868	597001	1	SEAL, Valve
883	597072	1	GASKET, Exhaust
914	597016	4	SCREW -(Rocker Cover)
1022	597015	1	GASKET, Rocker Cover
1023	597009	1	COVER, Rocker
1026	597017	2	ROD, Push
1029	596999	2	ARM, Rocker
1095	597140	1	GASKET SET, Valve -(Service Kits may include extra parts not specific to this engine.)
1263	697124	1	REED, Breather
1264	793453	1	SCREW -(Breather Reed)



Exhaust Group

REF NO	PART NO	QTY	DESCRIPTION
300	597071	1	MUFFLER -(With Mounting Bracket)
346	699203	3	SCREW -(Spark Arrestor)
613	590850	1	SCREW -(Muffler)
676	798467	1	Deflector-Muffler
832	597069	1	GUARD, Muffler
836	590706	3	Screw -(Muffler Guard)
883	597072	1	GASKET, Exhaust
994	793985	1	ARRESTOR, Spark
1177	590632	2	NUT -(Muffler)
1302	704133	3	LOCKWASHER, 1/4 -(Muffler Guard)
1449	590633	2	WASHER



Not For
Reproduction



Flywheel, Ignition, and Starter Group

REF NO	PART NO	QTY	DESCRIPTION
23	597085	1	FLYWHEEL
37	597075	1	GUARD, Flywheel
60	597080	2	GRIP, Starter Rope
65	590983	2	SCREW -(Rewind Starter)
78	590850	3	SCREW -(Flywheel Guard)
332	591988	1	Nut
333	596763	2	ARMATURE, Magneto
334	699477	2	SCREW -(Magneto Armature)
356	597054	1	WIRE, Stop
363	19203	1	PULLER, Flywheel
455	597088	1	CUP, Flywheel
608	596772	2	STARTER, Rewind
1005	794273	1	Fan-Flywheel

Not For
Reproduction



Fuel Supply Group

REF NO	PART NO	QTY	DESCRIPTION
187	597058	1	SLEEVE, Fuel Line
190	591476	1	SCREW -(Fuel Tank)
601	791850	1	CLAMP, Hose
705	707919	2	NUT -(Fuel Tank)
957A	596765	1	CAP, Fuel Tank
972	597057	1	TANK, Fuel
1345	792917	1	FILTER, Filler Neck
1357	597058	1	SLEEVE, Fuel Line

Not For
Reproduction

