







Parts Manual

Mfg. No: 10R232-0019-H5




Model Components	Page
Air Cleaner Group.	4
Blower Housing Group.	6
Carburetor Group.	8
Controls Group.	10
Crankcase Cover/Sump and Lubrication Group.	12
Crankshaft Group.	14
Cylinder Group.	16
Cylinder Head Group.	18
Exhaust Group.	20
Flywheel, Ignition, and Starter Group.	22
Fuel Supply Group.	24

Not For
Reproduction




Air Cleaner Group

REF NO	PART NO	QTY	DESCRIPTION
11	590698	1	TUBE, Breather
163	590605	1	GASKET, Air Cleaner
176	590695	1	SEAL, O-Ring -(Air Cleaner Base)
412	590697	1	NUT -(Air Cleaner Cover)
445	590601	1	FILTER, A/C Cartridge
467	691985	1	KNOB, Air Cleaner Cover
875	84004708	1	BASE, AIR CLEANER
968	597384	1	COVER, Air Cleaner
971	590643	1	SCREW -(Air Cleaner Base to Carburetor/Throttle Body)



Blower Housing Group


REF NO	PART NO	QTY	DESCRIPTION
304	84007295	1	HOUSING, Blower
305	590850	4	SCREW -(Blower Housing)
305A	597078	4	SCREW -(Blower Housing)
1036	-----	1	LABEL, Emissions -(Available from a Briggs & Stratton Authorized Dealer)
1319	794467	1	LABEL, Warning -(Required When Replacing Parts With Warning Labels Affixed)
1319A	797669	1	LABEL, Warning -(Required When Replacing Parts With Warning Labels Affixed)




Carburetor Group

REF NO	PART NO	QTY	DESCRIPTION
51	-----	1	GASKET, Intake -(Part information located in Cylinder Head Group.)
51A	-----	1	GASKET, Intake -(Part information located in Cylinder Head Group.)
53	590691	2	STUD -(Carburetor)
104	592486	1	PIN, Float Hinge
117	593414	1	JET, Main -(Standard)
118	593415	1	JET, Main -(High Altitude)
121	594958	1	KIT, Carburetor Overhaul -(Service Kits may include extra parts not specific to this engine.)
122	590615	1	SPACER, Carburetor
125	595649	1	CARBURETOR
163	-----	1	GASKET, Air Cleaner -(Part information located in Air Cleaner Group.)
654	590692	2	NUT -(Carburetor)
951	590614	1	LEVER, Choke

222A



202



209



227


562




505



347





789




Controls Group

REF NO	PART NO	QTY	DESCRIPTION
202	591438	1	LINK, Mechanical Governor
209	591624	1	SPRING, Governor
222A	591614	1	BRACKET, Control
227	590660	1	LEVER, Governor Control
347	597431	1	SWITCH, Rocker
505	590641	1	NUT -(Governor Control Lever)
562	590640	1	BOLT -(Governor Control Lever)
789	84004825	1	WIRE ASSEMBLY



Crankcase Cover/Sump and Lubrication Group


REF NO	PART NO	QTY	DESCRIPTION
3	-----	1	SEAL, Oil -(Part information located in Cylinder Group.)
7	-----	1	GASKET, Cylinder Head -(Part information located in Cylinder Head Group.)
12	590608	1	GASKET, Crankcase
18	84002446	1	COVER, Crankcase
20	590712	1	SEAL, Oil -(PTO Side)
22	590714	6	SCREW -(Crankcase Cover/Sump)
51	-----	1	GASKET, Intake -(Part information located in Cylinder Head Group.)
51A	-----	1	GASKET, Intake -(Part information located in Cylinder Head Group.)
163	-----	1	GASKET, Air Cleaner -(Part information located in Air Cleaner Group.)
358	-----	1	GASKET SET, Engine
522	590716	2	PLUG, Dipstick/Fill
718A	590714	2	SCREW
868	-----	1	SEAL, Valve -(Part information located in Cylinder Head Group.)
883	-----	1	GASKET, Exhaust -(Part information located in Exhaust Group.)
1022	-----	1	GASKET, Rocker Cover -(Part information located in Cylinder Head Group.)
1548	590715	1	BEARING, Ball -(Crankcase Cover/Sump)



Crankshaft Group

REF NO	PART NO	QTY	DESCRIPTION
16	595077	1	CRANKSHAFT
25	595076	1	PISTON ASSEMBLY
26	590661	1	SET, Ring
27	590664	2	LOCK, Piston Pin
28	590663	2	PIN, Piston
29	84002448	1	ROD, Connecting
46	84007513	1	CAMSHAFT
357	798305	1	KEY, Drive Pulley



Not For Reproduction



614

404


616



307


Cylinder Group

REF NO	PART NO	QTY	DESCRIPTION
1	84002087	1	CYLINDER ASSEMBLY
3	590712	1	SEAL, Oil -(Magneto Side)
15	590678	2	PLUG, Oil Drain
17	590715	1	BEARING, Ball -(Cylinder)
220	590677	1	WASHER -(Governor Gear)
220A	590675	1	WASHER -(Governor Gear)
221	590676	1	CUP, Governor
227	-----	1	LEVER, Governor Control -(Part information located in Controls Group.)
306	590636	1	SHIELD, Cylinder
307	590683	2	SCREW -(Cylinder Shield)
404	590669	1	WASHER -(Governor Crank)
614	590670	1	PIN, Cotter
616	590668	1	CRANK, Governor
718	590637	2	PIN, Locating
718A	-----	2	PIN, Locating -(Part information located in Crankcase Cover/Sump Group.)




Cylinder Head Group

REF NO	PART NO	QTY	DESCRIPTION
3	-----	1	SEAL, Oil -(Part information located in Cylinder Group.)
7	590606	1	GASKET, Cylinder Head
12	-----	1	GASKET, Crankcase -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
13	590639	4	SCREW -(Cylinder Head)
20	-----	1	SEAL, Oil -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
33	591448	1	VALVE, Exhaust
34	591447	1	VALVE, Intake
35	590650	1	SPRING, Valve -(Intake)
36	590650	1	SPRING, Valve -(Exhaust)
40	590654	2	RETAINER, Valve
45	590657	2	TAPPET, Valve
51	590612	1	GASKET, Intake
51A	590613	1	GASKET, Intake
53	-----	2	STUD -(Part information located in Carburetor Group.)
155	592874	1	PLATE, Cylinder Head
163	-----	1	GASKET, Air Cleaner -(Part information located in Air Cleaner Group.)
238	590649	2	CAP, Valve
337	691043	1	PLUG, Spark
358	594951	1	GASKET SET, Engine
383	590721	1	WRENCH, Spark Plug
830	590653	2	STUD, Rocker Arm
868	590648	1	SEAL, Valve
883	-----	1	GASKET, Exhaust -(Part information located in Exhaust Group.)
1022	797194	1	GASKET, Rocker Cover
1023	592903	1	COVER, Rocker
1026	590658	2	ROD, Push
1029	590651	2	ARM, Rocker









Exhaust Group

REF NO	PART NO	QTY	DESCRIPTION
296	590631	2	STUD -(Muffler)
300A	591618	1	MUFFLER
676B	591711	1	DEFLECTOR, Muffler
832A	591619	1	GUARD, Muffler
836A	590850	3	SCREW -(Muffler Guard)
883	591156	1	GASKET, Exhaust
1177	590632	2	NUT -(Muffler)
1302	590457	3	WASHER -(Muffler Guard)
1449	590633	2	WASHER -(Muffler)



Flywheel, Ignition, and Starter Group

REF NO	PART NO	QTY	DESCRIPTION
23	595228	1	FLYWHEEL
37	592865	1	GUARD, Flywheel
58	693389	1	ROPE, Starter -(Cut To Required Length)
65	590683	3	SCREW -(Rewind Starter)
78	590643	1	SCREW -(Flywheel Guard)
332	590635	1	NUT -(Flywheel)
333	590603	1	ARMATURE, Magneto
334	590644	2	SCREW -(Magneto Armature)
455	590682	1	CUP, Flywheel
608	590607	1	STARTER, Rewind
1005	590679	1	FAN, Flywheel



Fuel Supply Group

REF NO	PART NO	QTY	DESCRIPTION
187	791766	1	LINE, Fuel
190	590643	1	SCREW -(Fuel Tank)
601	791850	2	CLAMP, Hose
705	590692	2	NUT -(Fuel Tank)
957A	794641	1	CAP, Fuel Tank
972	595650	1	TANK, Fuel
1345	792917	1	FILTER, Filler Neck
1357	590688	1	SLEEVE, Fuel Line
1509	797346	1	OUTLET, Tank

