

No.	Name	Qty.	No.	Name	Qty.
1	Main frame	1	21	Sliding plate pin	1
2	Tyre stand	1	22	Push head	1
3	Gear shaft	1	23	Up sliding plate	1
4	Gear shaft key	2	24	Copper plate	1
5	FCS208 bearing	2	25	Leaf spring	1
6	Fly wheel	2	26	Guiding axle frame	1
7	Belt	2	27	61900 bearing	2
8	Draw baw	1	28	Guiding axle bearing bushing	2
9	Coupler	1	29	Shock pad	2
10	Stand	1	30	HK1312 bearing	2
11	Pinch roller frame	1	31	Left firewood plate	1
12	CYR bearing	6	32	40mm angle steel	2
13	Rack rod	1	33	Right firewood plate	1
14	Piston rod	1	34	Tyre stand connect plate	1
15	Bar 1	1	35	Tyre	2
16	Bar 2	1	36	Engine connect plate	2
17	Hex nut	1	37	Gasoline engine	1
18	Handle connecting rod	1	38	Clutch	1
19	Bottom sliding plate	2	39	Belt cover	1
20	Fly wheel gland	2	40	Fly wheel cover	1